

# The $PLPAK^{TM}$

# **BIM Single-Floor MANUAL**

PLPAK<sup>™</sup> Version 2.00

#### STRUCTURAL ANALYSIS SOFTWARE USING

THE BOUNDARY ELEMENTS METHOD

Copyright © 2000-2022 https://www.plpak.com

E-mail: plpak@be4e.com

#### Disclaimer

Considerable time, effort and expense have gone into the development and documentation of the PLPAK<sup>TM</sup> software. The PLPAK<sup>TM</sup> software has been thoroughly tested and used. The PLPAK<sup>TM</sup> software should be used by engineers with good understanding of concrete behavior, pre-stressing and structural mechanics. The user accepts and understands that no warranty is expressed or implied by the developers or the distributors on the accuracy or the reliability of the PLPAK<sup>TM</sup> software. The user must explicitly understand the assumptions of the PLPAK<sup>TM</sup> software and must independently verify the results produced by the PLPAK<sup>TM</sup> software.

# Copyright

Copyright © BE4E.com, 2000-2022 All rights reserved.

The PLPAK<sup>TM</sup>, PLGen<sup>TM</sup>, PLView<sup>TM</sup>, PLCoreMan<sup>TM</sup>, PLPost<sup>TM</sup>, PTPAK<sup>TM</sup>, PL<sup>TM</sup>, PL.EXE<sup>TM</sup> are registered trademarks of BE4E.com.

The computer program PLPAK<sup>TM</sup> and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with BE4E.com. Unlicensed use of these programs or reproduction of documentation in any form, without prior written authorization from BE4E.com is explicitly prohibited.

No part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior explicit written permission of the BE4E.com.

Further information and copies of this documentation may be obtained from:

<u>Technical director:</u> Youssef F. Rashed, PhD Department of structural engineering, Cairo University, Egypt.

e-mail: <u>plpak@be4e.com</u> web: <u>https://www.plpak.com</u>

# The Single-Floor Package

#### 1 Package description

This package is part of the PLPAK-Revit extension. The Single-Floor Package provide the full capability of PLPAK-Revit Link within one floor problem.

#### 2 Capabilities

- 1- Export model to PLPAK basic package
- 2- Possibility of review and edit the problem in PLGEN before solve it.
- 3- Full feature of post processing packages (PLPost, PLDesign, PTPak).
- 4- Prepare design note and RFT details.
- 5- Export RFT detail to Revit model.

### 3 What's new in this package

- 1 Simplified and fast tool to export floors from Revit to PLPAK
- 2 Possibility of review and edit the problem in PLGEN before solve it

#### 3 Screen shots





Model Summary 0/0 Undefined 0/1 Slabs 0/4 Openings 0/58 Columns 0/6 Beams 0/0 Load Patches 0/0 Column Loads 0/0 Wall Loads 0/0 Wall Supports 0/12 Soil Supports 0/12 Soil Supports 0/12 Soil Supports 0/42 Soil Supports 0/42



BE4E-PLDesign - [Floor_ID_353504	hLL-title1-DL]		$ \Box$ $>$
File View Action Desig		Ja Carlor	- 5
	🛛 🔍 Re 🍳 🖳 🕂 🇰 🔯 🍯 🍏 🍆 🖆 🗗 🗳 🗗 🤻 BCs Loads BCs Legend Supports Reactions Assemblies Legend Slabs Beams Beams Data Punching critical section	ons	
esults Manager Select Case Bea	ms Manager Assemblies Manager Define model details Design Slabs Design Beams Punching check Deflection Strips Match properties Start detailing		
Edit Design Slab			
Region 2			
Desgin slabs list:	Strip properties		
Area 1 X	Width: 0 Status: Toteschurd - Show enabled		
	Major design Mox  Material: Default Tonf-m  Envelope design.		
	parameter: /combination: // Envelope:		
	Top major steel Bottom major steel Top minor steel Bottom minor steel Refresh		
	Bar diameter: 0.01 Number of required rebars: required rebars: Add additional Calculate moment Add additional		
	Maximum +ve bending moment: Maximum -ve bending moment: 2.03912979799274 Add additional reirforcement! batches		
Desgin slab spans:	Span properties		
Span 1	Span properties Slab thickness: 0.22 Singly reinforced.  Force doubly reinforced section.		
	Cover: 0.025 Alpha Major: 0.2		
	Top cover: 0.025 Alpha minor: 0.2		
	Top major steel Bottom major steel Top minor steel Bottom minor steel		
	Asteel top major direction:		
	Bar diameter: 0.01 Number of required rebars: 0		
Errors:			
Errors in major direction:			
Errors in minor direction:			
	Close		
T I			
		PL	DESIGN
rrent Load Case: DL Current Lo			



## **Getting Help**

The BE4E.com customer support team is always welcoming problems and suggestions of registered customers. Just send an e-mail including your questions, or your model together with your questions to: <a href="mailto:plpak@be4e.com">plpak@be4e.com</a>

Also check our site news at <u>www.plpak.com</u> regularly for *Problems and Solutions* section and the *Frequently Asked Questions* section